
BLK
BATTERY
RED
RELAY MODULE, STARTER, GENERATOR, ENGINE CONTROL MODULE
PASSENGER SIDE FUSE & RELAY MODULE BOX
REAR FUSE BOX
FUSE 1 20A
FUSE 2 20A
FUSE 3 10A
FUSE 4 25A
FUSE 5 25A
FUSE 6 25A
FUSE 7 20A
FUSE 8 25A
FUSE 9 25A
FUSE 10 10A
FUSE 11 7.5A
FUSE 12 25A
FUSE 13 25A
FUSE 14 25A
FUSE 15 7.5A
FUSE 16 25A
FUSE 17 20A
FUSE 18 20A
FUSE 19 40A
RED/BLK
RED/YEL
RED/GRY
RED/BLK
BRN (OR RED/WHT)
RED/BLK/WHT
RED/BLU
RED/YEL/GRY
RED/YEL/WHT
RED/BLU
RED/BLU/YEL
(NOT USED)
RED/YEL/BLK
RED/GRN/WHT
RED/BLU/VIO
RED/BLU/WHT
(NOT USED)
RED/GRN/GRY
RED/GRN
PASSENGER SIDE DOOR CONTROL MODULE
REAR PASSENGER SIDE DOOR CONTROL MODULE
ROOF CONTROL UNIT CONTROL MODULE
FUEL PUMP RELAY MODULE
LEFT FRONT ELECTRONIC SEAT ADJUSTMENT CONTROL MODULE
TV TUNER
RIGHT FRONT ELECTRONIC SEAT ADJUSTMENT CONTROL MODULE
FRONT HEATED SEAT CONTROL MODULE, FRONT HEATED SEAT & SEAT VENTILATION CONTROL MODULE
PSE CONTROL MODULE
LOWER CONTROL FIELD CONTROL MODULE, SEATS SYSTEM, INTERIOR LIGHTS SYSTEM
PSE CONTROL MODULE, RADIO, OPERATING MONITORING SYSTEM OPERATING MODULE
TAILGATE CLOSING ASSIST
STEERING ANGLE SENSOR, ALARM SIREN
CTEL TRANSMITTER-RECEIVER
LEFT/RIGHT AUDIO POWER AMPLIFIER
W/ IN-LINE ENGINE
W/O IN-LINE ENGINE
TERMINAL BLOCK (X4/31)
TERMINAL BLOCK (X4)
TERMINAL BLOCK (X12/3)
A3 30
A2 30
B7 30
ELECTRONIC IGNITION-STARTER SWITCH CONTROL MODULE
A6 30
A1 15
A4 15R
D6 15
B12 15X
A5 P30
B9 50
B9 50
B3 GND
DRIVER SIDE FUSE & RELAY MODULE BOX
1 M2
2 C2
1 C1
PNK/RED
PNK/YEL
BLK/RED
PNK/GRN
GRN/WHT
WHT/GRN
VIO
BRN
W1
CRUISE CONTROL SWITCH
ILLUMINATION CONTROL MODULE
AIR CONDITIONING SYSTEM
DRIVER SIDE FUSE & RELAY MODULE BOX
FUSE & RELAY BOX
FUSE 16 20A
FUSE 17 20A (OR 10A)
FUSE 18 20A
FUSE 20 50A (E320) 30A (E430)
FUSE 4 10A
FUSE 5 15A
RED/BLK
RED/BLU
RED/BLK
RED/BLK
RED/BLU
RED/YEL
DRIVER SIDE DOOR CONTROL MODULE
DATA LINK CONNECTOR, DIAGNOSTIC MODULE (OBD II) CONNECTOR
REAR DRIVER SIDE DOOR CONTROL MODULE
AUXILIARY/ ELECTRICAL COOLING FAN CONTROL MODULE
INSTRUMENT CLUSTER, A/C PUSHBUTTON CONTROL MODULE
EXTERIOR LIGHTS SYSTEM
PNK/ RED
C3 15
PASSENGER SIDE FUSE & RELAY MODULE BOX
FUSE & RELAY BOX
FUSE 9 15A
FUSE 19 40A
FUSE 13 10A
FUSE 14 15A (OR 7.5A)
FUSE 15 15A
FUSE 7 15A
FUSE 1 15A
FUSE 2 15A
FUSE 3 15A
FUSE 11 15A
FUSE 12 10A
FUSE 10 10A
FUSE 23 7.5A
RED/GRN
BLK/YEL (OR RED/YEL)
BLK/BLU (OR BLK/YEL)
BLK/BLU
BLK/VIO
BLK/RED
BLK/YEL
BLK/YEL
BLK/WHT
BLK/RED/VIO (OR BLK/YEL)
BLK/WHT
BLK/GRN (OR BLK/YEL)
BLK/YEL/GRN
W/ INTERIOR LIGHTS PACKAGE
W/O INTERIOR LIGHTS PACKAGE
IGNITION COILS, ESP/SPS/BAS CONTROL MODULE, ASR/ETS/ESP HYDRAULIC UNIT
REAR WINDOW WIPER MOTOR, OUTSIDE REARVIEW MIRROR SWITCH, RCL CONTROL MODULE, IR/DAS CONTROL MODULE
INSTRUMENT CLUSTER, A/C PUSHBUTTON CONTROL MODULE
INTERIOR LIGHTS SYSTEM
GRY/VIO
GLOVE COMPARTMENT LAMP, COMBINATION SWITCH
CARGO AREA CONNECTOR, RADIO
INSTRUMENT CLUSTER, SUPPLEMENTAL RESTRAINTS SYSTEM
CTEL TRANSMITTER-RECEIVER
NCA
CIGARETTE LIGHTER
ESC CONTROL MODULE
INSTRUMENT CLUSTER, SUPPLEMENTAL RESTRAINTS SYSTEM
DATA LINK CONNECTOR, R/P LOCK SOLENOID, KICKDOWN CUT-OUT RELAY MODULE, ULTRASONIC PTS CONTROL MODULE, HEADLAMP RANGE ADJUSTMENT CONTROL MODULE
REAR WINDOW SUNSHADE SWITCH, FRONT HEATED SEAT CONTROL MODULE, FRONT HEATED SEAT & SEAT VENTILATION CONTROL MODULE, LEFT FRONT SEAT BELT COMFORT SOLENOID, RIGHT FRONT SEAT BELT COMFORT SOLENOID
BRN
W1
158234