
ENGINE 646.951 in MODEL 211.004

ENGINE 646.961 in MODELS 211.006 /206 /606 ENGINE 647.961 in MODELS 211.016 /216 /616 ENGINE 271.941 in MODELS 211.042 /242

ENGINE 648.961 in MODELS 211.023 /026 /223 /226



P20.40-2044-09

## Shown on model 211.006

- Rubber seal
- Radiator crossmember
- Bolts
- Flat spring Fan shroud
- Coolant hose

- Bracket
- 8 Connector Retaining lug

XX	Removing/installing		
⚠ Danger!	Risk of injury caused by fingers being jammed or pinched when removing, installing or aligning hoods, doors, trunk lid/rear-end door or sliding roof.  Open engine hood	When moving components, ensure that no body parts or limbs are within the operating range of moving parts.	AS00.00-Z-0011-01A AR88.40-P-1000T
↑ Danger!	Risk of explosion caused by oxyhydrogen	No fire, sparks, open flames or smoking.	AS54.10-Z-0001-01A
کنے Danger!	gas. Risk of poisoning and caustic burns caused by swallowing battery acid. Risk of injury caused by burns to skin and eyes from battery acid or when handling damaged leadacid batteries	Wear acid-resistant gloves, clothing and safety glasses. Only pour battery acid into suitable and appropriately marked containers.	
2	Disconnect ground cable from battery	Insulate ground line to prevent unintentional contact between the detached ground line and battery ground point.  Model 211.0/6	AR54.10-P-0003T
		Model 211.2	AR54.10-P-0003TA
<b>()</b>	Notes on battery		AH54.10-P-0001-01A
3.1	Remove engine intake air duct upstream of the air cleaner	Model 211.042/242	
4.1	Remove trim panels for cylinder head cover	Engines 646, 647	AR01.20-P-5014-02A
		Engine 648	AR01.20-P-5014-02C
		Nm Bolt for cylinder head cover trim panel on cylinder head	*BA01.20-P-1002-01G
		Nm Bolt for trim panel on charge air distribution pipe	*BA01.20-P-1003-01G
5	Remove rubber seal (1) in the region of the radiator crossmember (2)		
6	Unscrew screw (3) and fold up radiator crossmember (2) to the front by about 180°	Bolt for center reinforcement on outer reinforcement  Bolt for center reinforcement on catch hook reinforcement	*BA62.30-P-1008-02A *BA62.30-P-1009-02A
7	Pull out flat springs (4) on the upper side of the fan shroud (5)		

8	Slacken coolant hose (6) from brackets (7) at fan shroud (5)		
9	Detach the connector (8) from the fan shroud (5)		
10	Take out fan shroud (5) towards top	i Installation: Insert the retaining lugs of the fan shroud (5) into the mounts at the radiator (9).	
11	Install in reverse order		
12.1	Check setting of Distronic sensor	For vehicles with Distronic code 219a	AR30.30-P-1000R

## $\overline{\mbox{\scriptsize Nm}}$ Crankcase ventilation, cylinder head cover

Number	Designation	Engines 646.951/961, 647.961	Engine 648
BA01.20-P-1002-01G	Bolt for trim panel of cylinder Nm head cover on cylinder head	9	9
BA01.20-P-1003-01G	Bolt for cover to Nm charge air distribution pipe	9	9

## $\overline{\mbox{\scriptsize Nm}}$ Front end assembly with front reinforcement

Number	Designation	Model 211
BA62.30-P-1008-02A	Bolt for center reinforcement on outer Nm reinforcement	10
BA62.30-P-1009-02A	Bolt for center reinforcement on arrester Nm hook reinforcement	10